MODEL: uIBX-200-VX800

Ultra Compact Embedded System with CompactFlash® Slot VGA, Gigabit Ethernet, 4 x USB, 802.11b/g Wireless, Line out, Mic, 2 x RS-232, RoHS Compliant

Standard SIB

User Manual



in lithe Cin-

INVESTIGATION OF

0

Rev. 1.01 - 2009

Revision

Date	Version	Changes
4 December, 2009	1.01	Added BIOS chapter
27 August, 2009	1.00	Initial release

Copyright

COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Table of Contents

1 INTRODUCTION	1
1.1 Overview	2
1.2 Benefits	2
1.3 Features	3
1.4 TECHNICAL SPECIFICATIONS	3
1.5 CERTIFICATIONS	4
2 DETAILED SPECIFICATIONS	5
2.1 FRONT PANEL	б
2.2 REAR CONNECTOR PANEL	б
2.3 DIMENSIONS	8
2.4 MAINTENANCE	8
3 UNPACKING	9
3.1 Anti-static Precautions	0
3.2 UNPACKING PRECAUTIONS	0
3.3 UNPACKING CHECKLIST	1
3.4 Optional Items	2
4 INSTALLATION	3
4.1 INSTALLATION PRECAUTIONS	4
4.2 JUMPER SETTINGS	5
4.2.1 AT/ATX Power Select Jumper Settings15	5
4.2.2 CompactFlash® Master/Slave Selection10	5
4.2.3 Clear CMOS Jumper 10	5
4.3 COMPACTFLASH® CARD INSTALLATION	б
4.4 EXTERNAL PERIPHERAL INTERFACE CONNECTORS	7
4.4.1 Power Input	8
4.4.2 Audio Connector	9
4.4.3 LAN Connectors	9
4.4.4 Serial Port Connector	1

4.4.5 USB Connector	
4.4.6 VGA Connector	
4.5 MOUNTING THE SYSTEM	
4.6 Software	
5 BIOS	
5.1 INTRODUCTION	
5.1.1 Starting Setup	
5.1.2 Using Setup	
5.1.3 Getting Help	
5.1.4 Unable to Reboot After Configuration Changes	
5.1.5 BIOS Menu Bar	
5.2 MAIN	
5.3 Advanced	
5.3.1 CPU Configuration	
5.3.2 IDE Configuration	
5.3.2.1 SATA Channel	
5.3.3 Super IO Configuration	
5.3.4 Power Configuration	
5.3.4.1 ACPI Configuration	
5.3.4.2 APM Configuration	
5.3.5 Remote Access Configuration	
5.3.6 USB Configuration	
5.3.6.1 USB Mass Storage Device Configuration	
5.4 PCI/PNP	
5.5 Воот	
5.5.1 Boot Settings Configuration	
5.5.2 Boot Device Priority	
5.5.3 Hard Disk Drives	
5.5.4 Removable Drives	55
5.5.5 CD/DVD Drives	
5.6 Security	
5.7 Chipset	
5.7.1 Northbridge VIA® VX800 Configuration	
5.7.2 Southbridge VIA® VX800 Configuration	59

5.8 EXIT	60
A SAFETY PRECAUTIONS	62
A.1 SAFETY PRECAUTIONS	63
A.1.1 General Safety Precautions	63
A.1.2 Anti-static Precautions	64
A.2 MAINTENANCE AND CLEANING PRECAUTIONS	64
A.2.1 Maintenance and Cleaning	64
A.2.2 Cleaning Tools	65
B HAZARDOUS MATERIALS DISCLOSURE	66
B.1 HAZARDOUS MATERIALS DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS	
RoHS Compliant Under 2002/95/EC Without Mercury	67

List of Figures

Figure 1-1: uIBX-200-VX8002
Figure 2-1: Front Panel6
Figure 2-2: uIBX-200-VX800 Peripheral Connectors7
Figure 2-3: Physical Dimensions (millimeters)8
Figure 4-1: CompactFlash® Card Installation17
Figure 4-2: Peripheral Connectors (Rear)18
Figure 4–3: Peripheral Connectors (Front)18
Figure 4-4: Power Terminal Block19
Figure 4-5: Audio Connector19
Figure 4-6: LAN Connection20
Figure 4-7: RJ-45 Ethernet Connector20
Figure 4-8: Serial Device Connector Error! Bookmark not defined.
Figure 4-9: Serial Port Pinouts22
Figure 4-10: USB Device Connection Error! Bookmark not defined.
Figure 4-11: VGA Connector23
Figure 4-12: VGA Connector23
Figure 4–13: Attachment Installation24
Figure 4–14: System Attachment Screws25
Figure 4–15: Mounting Screws26

List of Tables

Table 1-1: Technical Specifications	4
Table 3-1: Package List Contents	11
Table 3-2: Optional Items	12
Table 4-1: Jumpers	15
Table 4-2: AT/ATX Power Select Jumper Settings	15
Table 4-3: CompactFlash® Master/Slave Selection	16
Table 4-4: Clear BIOS Jumper Settings	16
Table 4-5: LAN Pinouts	20
Table 4-6: RJ-45 Ethernet Connector LEDs	21
Table 4-7: Serial Port Pinouts	21
Table 4-8: USB Port Pinouts	22
Table 4-9: VGA Connector Pinouts	23
Table 5-1: BIOS Navigation Keys	30



Introduction

1.1 Overview



Figure 1-1: uIBX-200-VX800

The uIBX-200-VX800 embedded system is an ultra small PC for installation between a computer screen and its stand. It is powered by the VIA® Eden[™] ULV 1 GHz/500 MHz processor, uses the VIA® VX800 system chip and has 1.0 GB or 512 MB of DDR2 memory.

The VIA® VX800 system chip provides many built-in graphics functions allowing high quality video playback without the need for expensive hardware.

The uIBX-200-VX800 is best when combined with the optional CompactFlash® card with Microsoft® Windows XP Embedded or Linux preinstalled. A software development kit and documentation are also available to help easily customize the operating system according to the installation requirements.

1.2 Benefits

Some of the uIBX-200-VX800 benefits include:

- Customizable operating system to suit application needs.
- Less downtime from overheating because there are not fans to fail
- Cost savings with low power consumption
- Easy installation on standard VESA mounting
- Both wired and wireless network connectivity

1.3 Features

The uIBX-200-VX800 features are listed below:

- VIA® Eden[™] ULV 1 GHz/500 MHz processor
- 1.0 GB or 512 MB of DDR2
- VGA video output
- One Gigabit Ethernet port
- Four USB 2.0 ports
- Two RS-232 serial ports
- RoHS compliant

1.4 Technical Specifications

The uIBX-200-VX800 technical specifications are listed in Table 1-1.

Specifications		
System		
CPU	VIA® Eden™ ULV 1 GHz/500 MHz processor	
Memory	1.0 GB or 512 MB of DDR2 memory	
Real-time Clock	Battery backup RTC	
Watchdog Timer	Software programmable supports 1~255 sec. system reset	
Reset	Reset button	
Display		
Video Output	VGA	
Video Support	Integrated graphics processor with 2D / 3D / Video controllers 2D and 3D graphics processor Supports MPEG2, WMV9 / VC1 decoding (Standard drivers provide the DirectX Video Acceleration interface to enable video acceleration. User application protocols need to use the DirectX Video Acceleration interface to enable the acceleration features)	

Specifications		
I/O and Communications		
Ethernet	1 x 10/100/1000 Mb/s	
	1 x 802.11b/g (optional)	
Serial Ports	2 x RS-232	
USB Interfaces	4 x USB 2.0 host connectors	
Audio	Line out	
	Microphone in	
Power		
Power Supply	5 VDC	
Power Consumption	15 W	
Environmental and Mechanical		
Operating Temperature 0°C~50°C		
Humidity	5%RH to 90%RH (non-condensing)	
Vibration	Operating Random Vibration Mode (MIL-STD-810F	
	514.5C-3)	
	1.Axes: 3 axs (Vertical / Transverse / Longitudinal).	
	2.10-500 Hz, 60min/axis.	
	3.Equivalent to Z:2.18 Grms X:1.6 Grms Y:1.96 Grms	
Color	Black front, sides and bottom.	
	Light gray top and back	
Physical Dimensions	120 mm x 44.4 mm x 125 mm	


Table 1-1: Technica	I Specifications
---------------------	------------------

1.5 Certifications

All uIBX-200-VX800 series models comply with the following international standards:

- RoHS
- CE, FCC Class A, CCC

For a more detailed description of these standards, please refer to **Appendix A**.



Detailed Specifications

2.1 Front Panel

The front panel consists of a small door, giving access to the CompactFlash® card, and also has two USB ports, an audio output and microphone input jack.




Figure 2-1: Front Panel

Connectors and buttons on the front panel include the following.

- 1 x CompactFlash® slot
- 2 x USB connectors
- 1 x Microphone input
- 1 x Line output

2.2 Rear Connector Panel

All external peripheral interface connectors are located on the bottom panel of the uIBX-200-VX800. The peripheral interface connectors are shown in Figure 2-2.




Figure 2-2: uIBX-200-VX800 Peripheral Connectors

Connectors and buttons on the rear panel include the following.

- 1 x 5 V DC power input
- 1 x Power switch
- 1 x VGA output
- 2 x RS-232 ports
- 2 x USB ports
- 1 x Gigabit Ethernet port
- 1 x Antenna connector (certain models only)

2.3 Dimensions

The physical dimensions are shown and listed below:

- Width: 120 mm
- Height: 44.4 mm
- Depth: 125 mm





Figure 2-3: Physical Dimensions (millimeters)

2.4 Maintenance

Don't open the uIBX-200-VX800 (except the CompactFlash® door), there are no user-serviceable parts inside.



Unpacking

3.1 Anti-static Precautions



Failure to take ESD precautions during installation may result in permanent damage to the uIBX-200-VX800 and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the uIBX-200-VX800. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the uIBX-200-VX800 or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- *Wear an anti-static wristband*: Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- Self-grounding: Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- Use an anti-static pad: When configuring the uIBX-200-VX800, place it on an antic-static pad. This reduces the possibility of ESD damaging the uIBX-200-VX800.

3.2 Unpacking Precautions

When the uIBX-200-VX800 is unpacked, please do the following:

- Follow the anti-static precautions outlined in **Section 3.1**.
- Make sure the packing box is facing upwards so the uIBX-200-VX800 does not fall out of the box.
- Make sure all the components shown in **Section 3.3** are present.

3.3 Unpacking Checklist



If some of the components listed in the checklist below are missing, please do not proceed with the installation. Contact your sales representative directly. To contact us <u>http://www.emacinc.com/support/</u>

The uIBX-200-VX800 is shipped with the following components:


Quantity	Item and Part Number	Image
1	uIBX-200-VX800	
1	Power adapter	Le la
1	Screw set	PPPP
1	Quick installation guide	
1	Driver CD	

Table 3-1: Package List Contents

3.4 Optional Items

Quantity	Item	Image
ulBXVK-200B	Double side VESA mount kit for uIBX-200, black	

Table 3-2: Optional Items



Installation

4.1 Installation Precautions


During installation, be aware of the precautions below:

- Read the user manual: The user manual provides a complete description of the uIBX-200-VX800, installation instructions and configuration options.
- DANGER! Disconnect Power: Power to the uIBX-200-VX800 must be disconnected during the installation process, or before any attempt is made to access the rear panel. Electric shock and personal injury might occur if the rear panel of the uIBX-200-VX800 is opened while the power cord is still connected to an electrical outlet.
- Qualified Personnel: The uIBX-200-VX800 must be installed and operated only by trained and qualified personnel. Maintenance, upgrades, or repairs may only be carried out by qualified personnel who are familiar with the associated dangers.
- Air Circulation: Make sure there is sufficient air circulation when installing the uIBX-200-VX800. The uIBX-200-VX800's cooling vents must not be obstructed by any objects. Blocking the vents can cause overheating of the uIBX-200-VX800. Leave at least 5 cm of clearance around the uIBX-200-VX800 to prevent overheating.
- Grounding: The uIBX-200-VX800 should be properly grounded. The voltage feeds must not be overloaded. Adjust the cabling and provide external overcharge protection per the electrical values indicated on the label attached to the back of the uIBX-200-VX800.

4.2 Jumper Settings



A jumper is a metal bridge used to close an electrical circuit. It consists of two or three metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with



the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.

The hardware jumpers must be set before installation. Jumpers are shown in Table 4-1.

Description	Label	Туре
AT/ATX power select	JP3	2-pin header
CompactFlash® Master/Slave	CF_MS_SEL1	3-pin header
Clear CMOS	J_CMOS	3-pin header

Table 4-1: Jumpers

4.2.1 AT/ATX Power Select Jumper Settings

Jumper Label:	JP3
Jumper Type:	2-pin header
Jumper Settings:	See Table 4-2

The AT Power Select jumper specifies the systems power mode as AT or ATX.

Setting	Description
Open	Use AT power
Closed	Use ATX power

Table 4-2: AT/ATX Power Select Jumper Settings

4.2.2 CompactFlash® Master/Slave Selection

Jumper Label:	CF_MS_SEL1
Jumper Type:	3-pin header
Jumper Settings:	See Table 4-3

Set the CompactFlash® card as an IDE master or an IDE slave.

Setting	Description
1-2	Slave
2-3	Master

Table 4-3: CompactFlash® Master/Slave Selection

4.2.3 Clear CMOS Jumper

Jumper Label:	J_CMOS1
Jumper Type:	3-pin header
Jumper Settings:	See Table 4-4

To reset the BIOS, move the jumper to the "Clear BIOS" position for 3 seconds or more, then move back to the default position.

Setting	Description
1-2	Keep current BIOS setup
2-3	Clear BIOS

Table 4-4: Clear BIOS Jumper Settings

4.3 CompactFlash® Card Installation

The uIBX-200-VX800 supports a single CompactFlash® card. To install, follow the steps below.

Step 1: Unlock and open the cover door.

Step 2: Slide the CompactFlash® card into the slot.

Step 3: Close and lock the door.

Page 16



Figure 4-1: CompactFlash® Card Installation

4.4 External Peripheral Interface Connectors

The uIBX-200-VX800 has the following connectors. Detailed descriptions of the connectors can be found in the subsections below.

- Power input
- VGA
- USB
- Ethernet
- RS-232
- Antenna connector
- Line out
- Mic




Figure 4–3: Peripheral Connectors (Front)

4.4.1 Power Input

The power terminal block connects to the included 5 V DC power adapter.

CN Label: Power Input

CN Type:	KYCON KPPX-3P
CN Location:	See Figure 4-2
CN Pinouts:	See Figure 4-4



Figure 4-4: Power Terminal Block

4.4.2 Audio Connector

CN Label:	Line out, Mic
CN Type:	Audio jacks
CN Location:	See Figure 4–3

The audio jacks connect to external audio devices.

- Line Out port (Lime): Connects to a headphone or a speaker. With multi-channel configurations, this port can also connect to front speakers.
- Microphone (Pink): Connects a microphone.



Figure 4-5: Audio Connector

4.4.3 LAN Connectors

CN Label:	LAN
CN Type:	RJ-45
CN Location:	See Figure 4-2
CN Pinouts:	See Table 4-5

The LAN connectors allow connection to an external network.

- Step 1: Locate the RJ-45 connectors. The locations of the USB connectors are shown in Chapter 4.
- Step 2: Align the connectors. Align the RJ-45 connector on the LAN cable with one of the RJ-45 connectors on the uIBX-200-VX800. See Figure 4-6.



Figure 4-6: LAN Connection

Step 3: Insert the LAN cable RJ-45 connector. Once aligned, gently insert the LAN

cable RJ-45 connector into the on-board RJ-45 connector.

Pin	Description	Pin	Description
1	TXA+	5	TXC-
2	TXA-	6	TXB-
3	TXB+	7	TXD+
4	TXC+	8	TXD-

Table 4-5: LAN Pinouts



Figure 4-7: RJ-45 Ethernet Connector

The RJ-45 Ethernet connector has two status LEDs, one green and one yellow. The green LED indicates activity on the port and the yellow LED indicates the port is linked. See Table 4-6.

STATUS	DESCRIPTION	STATUS	DESCRIPTION
GREEN	Activity	YELLOW	Linked

Table 4-6: RJ-45 Ethernet Connector LEDs

4.4.4 Serial Port Connector

CN Label:	RS-232
CN Type:	DB-9 connectors
CN Location:	See Figure 4-2
CN Pinouts:	See Table 4-7 and Figure 4-8

RS-232 serial port devices can be attached to the DB-9 ports on the rear panel.

- Step 1: Locate the DB-9 connector. The location of the DB-9 connector is shown in Chapter 3.
- Step 2: Insert the serial connector. Insert the DB-9 connector of a serial device into the DB-9 connector on the external peripheral interface.
- **Step 3:** Secure the connector. Secure the serial device connector to the external interface by tightening the two retention screws on either side of the connector.

Pin	Description	Pin	Description
1	DCD	6	DSR
2	RX	7	RTS
3	ТХ	8	CTS
4	DTR	9	RI
5	GND		

Table 4-7: Serial Port Pinouts




Figure 4-8: Serial Port Pinouts

4.4.5 USB Connector

CN Label:	USB	
CN Type:	USB port	
CN Location:	See Figure 4-2 and Figure 4–3	
CN Pinouts:	See Table 4-8	

The USB ports are for attaching USB peripheral devices to the system.

- Step 1: Located the USB connectors. The locations of the USB connectors are shown in Chapter 4.
- Step 2: Align the connectors. Align the USB device connector with one of the connectors.
- Step 3: Insert the device connector. Once aligned, gently insert the USB device connector into the on-board connector.

Pin	Description	Pin	Description
1	USBV3L 5 V	2	GND
3	USBP4N	4	USBP5P
5	USBP4P	6	USBP5N
7	GND	8	USBV3L 5 V

Table 4-8: USB Port Pinouts

4.4.6 VGA Connector

CN Label:	VGA
CN Type:	15-pin Female
CN Location:	See Figure 4-2
CN Pinouts:	See Figure 4-10 and Table 4-9

The VGA connector connects to a monitor that accepts VGA video input.

Step 4: Locate the female DB-15 connector. The location of the female DB-15 connector is shown in Chapter 3.

Step 5: Align the VGA connector. Align the male DB-15 connector on the VGA screen cable with the female DB-15 connector on the external peripheral interface.

Insert the VGA connector Once the connectors are properly aligned with the insert the male connector from the VGA screen into the female connector on the uIBX-200-VX800.

Figure 4-9: VGA Connector




Figure 4-10: VGA Connector

Pin	Description	Pin	Description
1	RED	2	GREEN
3	BLUE	4	NC
5	GND	6	GND
7	GND	8	GND
9	VCC / NC	10	GND
11	NC	12	DDC DAT
13	HSYNC	14	VSYNC
15	DDCCLK	\triangleright	

Table 4-9: VGA Connector Pinouts

4.5 Mounting the System

To install the uIBX-200-VX800 on the VESA mounting slot, between the monitor stand and the monitor, follow the instructions below.

Step 6: Fasten the attachment onto the VESA mounting on the back of the monitor.




Figure 4–11: Attachment Installation



It may be easier to perform the next two steps in reverse order, depending on installation conditions.

Step 7: Slide the uIBX-200-VX800 into the attachment and fasten the four screws indicated.



Figure 4–12: System Attachment Screws

Step 8: Attach the monitor and uIBX-200-VX800 to a stand using the VESA mounting holes on the uIBX-200-VX800.



Figure 4–13: Mounting Screws

Three common methods of mounting the uIBX-200-VX800 are listed in the subsections below.

4.6 Software

The uIBX-200-VX800 comes with a pre-installed Windows XPE, CE 6.0 or Linux 2.6.x operating system and a rich software application development kit. For information about configuring the operating system, adding remote management tools or additional software and drivers, refer to the utility CD. The uIBX-200-VX800 includes the following software:

- Standard Windows® CE6.0 professional version license.
- Optional Board Support Package (BSP) for customers to customize their own OS image.
- Attached Software Development Kit (SDK) for embedded Visual C++ to program Windows CE application.
- Built-in .NET Compact Framework support with related SDK
- Thin Client Technology, Microsoft RDP (Remote Desktop Protocol), to enable uIBX-200-VX800 to access Microsoft Windows® based applications installed on Microsoft Terminal Service server.
- Free pre-installed utilities for configuring and diagnosing your uIBX-200-VX800.

 Free remote management tools installed in laptop for remotely configuring, monitoring, and managing your uIBX-200-VX800.





5.1 Introduction

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.

5.1.1 Starting Setup

The AMI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

- 1. Press the DELETE key as soon as the system is turned on or
- 2. Press the **DELETE** key when the "**Press Del to enter SETUP**" message appears on the screen.

If the message disappears before the **DELETE** key is pressed, restart the computer and try again.

5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **Esc** to quit. Navigation keys are shown in.

Кеу	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
Esc key	Main Menu – Quit and not save changes into CMOS
	Status Page Setup Menu and Option Page Setup Menu
	Exit current page and return to Main Menu
Page Up key	Increase the numeric value or make changes
Page Dn key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option
	Page Setup Menu

Кеу	Function
F2 /F3 key	Change color from total 16 colors. F2 to select color forward.
F10 key	Save all the CMOS changes, only for Main Menu

Table 5-1: BIOS Navigation Keys

5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

5.1.4 Unable to Reboot After Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in Chapter **5**.

5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- Main Changes the basic system configuration.
- Advanced Changes the advanced system settings.
- PCIPnP Changes the advanced PCI/PnP Settings
- Boot Changes the system boot configuration.
- Security Sets User and Supervisor Passwords.
- Chipset Changes the chipset settings.
- Power Changes power management settings.
- Exit Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

5.2 Main

The **Main** BIOS menu (BIOS Menu 1) appears when the **BIOS Setup** program is entered. The **Main** menu gives an overview of the basic system information.

	BIOS SETUP UTILITY						
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit	
System Ov	verview					[ENTER], [TAB] or FT-TAB] to select a	
AMIBIOS					field	d.	
Version	:08.00.1	4					
Build Dat	e :07/03/09	9			Use	[+] or [-] to	
ID:	:B129MR1	2			confi	igure system time.	
Processor VIA® Eder Speed Count	r Processor :1000MHz :1						
	_				\leftrightarrow	Select Screen	
System Me					$\uparrow \downarrow$	Select Item	
Size	:896MB				Enter F1	r Go to SubScreen General Help	
System Ti	me		[16:38	3:10]	F10		
System Ti	me		[Fri (01/04/2002]	ESC	Exit	

v02.61 ©Copyright 1985-2006, American Megatrends, Inc.

BIOS Menu 1: Main

System Overview

The **System Overview** lists a brief summary of different system components. The fields in **System Overview** cannot be changed. The items shown in the system overview include:

- AMI BIOS: Displays auto-detected BIOS information
 - O Version: Current BIOS version
 - O Build Date: Date the current BIOS version was made
 - O ID: Installed BIOS ID
- Processor: Displays auto-detected CPU specifications
 - O Type: Names the currently installed processor
 - O Speed: Lists the processor speed
 - O Count: The number of CPUs on the motherboard
- System Memory: Displays the auto-detected system memory.
 - O Size: Lists memory size

The System Overview field also has two user configurable fields:

System Time [xx:xx:xx]

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

System Date [xx/xx/xx]

Use the **System Date** option to set the system date. Manually enter the day, month and year.

5.3 Advanced

Use the **Advanced** menu (BIOS Menu 2) to configure the CPU and peripheral devices through the following sub-menus:



Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.

- CPU Configuration (see **Section 5.3.1**)
- IDE Configuration (see Section 5.3.2)
- Super IO Configuration (see Section 5.3.3)
- Power Configuration (see **Section** □)
- Remote Access Configuration (see Section 5.3.5)
- USB Configuration (see Section 5.3.6)

			BIOS SET	UP UTILITY			
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit	
Advanced	Settings				Confi	gure CPU	
	WARNING: Setting wrong values in below sections may cause system to malfunction						
<pre>> CPU Configuration > IDE Configuration > SuperIO Configuration > Hardware Health Configuration > Power Configuration > Remote Access Configuration > USB Configuration </pre>							
	v02.61 ©Copyright 1985-2006, American Megatrends, Inc.						

BIOS Menu 2: Advanced

5.3.1 CPU Configuration

Use the **CPU Configuration** menu (BIOS Menu 3) to view detailed CPU specifications and configure the CPU.

			BIOS SETUR	P UTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
2	advanced rsion:3F.1	CPU setting 5	gs			
Manufacturer: VIA® VIA® Eden Processor 1000MHz Frequency: 1.00GHz FSB Speed: 400MHz						
Cache L1:	128 KB				\leftrightarrow	Select Screen
Cache L2:					$\uparrow \downarrow$	Select Item
Ratio Act	ual Value:	10			Enter F1 F10 ESC	Go to SubScreen General Help Save and Exit Exit
	v02.61	©Copyright	1985-2006	, American	Megatrends	, Inc.

BIOS Menu 3: CPU Configuration

The CPU Configuration menu (BIOS Menu 3) lists the following CPU details:

- Manufacturer: Lists the name of the CPU manufacturer
- Brand String: Lists the brand name of the CPU being used
- Frequency: Lists the CPU processing speed

- FSB Speed: Lists the FSB speed
- Cache L1: Lists the CPU L1 cache size
- Cache L2: Lists the CPU L2 cache size

5.3.2 IDE Configuration

Use the **IDE Configuration** menu (BIOS Menu 4) to change and/or set the configuration of the IDE devices installed in the system.

			BIOS SETU	P UTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
IDE Confi	guration					
Parallel	ATA IDE de	vices				
> Primary	IDE Maste	r	: [Not	Detected]		
> Seconda	ry IDE Mast	ter	: [Not	Detected]		
> Seconda	ry IDE Sla	ve	: [Not	Detected]		
					$\uparrow \downarrow$	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
	v02.61 0	OCopyright	1985-2006	, American	Megatrends	, Inc.

BIOS Menu 4: IDE Configuration

Parallel ATA IDE devices

Displays the settings for all the IDE devices. The devices listed below are available.

- Primary IDE Master
- Secondary IDE Master
- Secondary IDE Slave

5.3.2.1 SATA Channel

Sets the IDE configuration of the SATA channels.

			BIOS SETU	P UTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
Primary ID	E Master					t the type of device cted to the system
Device	:Not D	etected				
Type LBA/Large Mode Block (Multi-Sector Transfer) PIO Mode DMA Mode S.M.A.R.T. 32Bit Data Transfer		[Auto] [Auto] [Auto] [Auto] [Auto] [Enable		F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit	
	v02.61 ©	Copyright	1985-2006	, American	Megatrends	, Inc.

BIOS Menu 5: IDE Master and IDE Slave Configuration

Type [Auto]

Use the **Type** BIOS option select the type of device the AMIBIOS attempts to boot from after the Power-On Self-Test (POST) is complete.

→	Not Installed		BIOS is prevented from searching for an IDE disk drive on the specified channel.
→	Auto	DEFAULT	The BIOS auto detects the IDE disk drive type attached to the specified channel. This setting should
			be used if an IDE hard disk drive is attached to the specified channel.
→	CD/DVD		The CD/DVD option specifies that an IDE CD-ROM drive is attached to the specified IDE channel. The BIOS does not attempt to search for other types of IDE disk drives on the specified channel.

ARMD
 This option specifies an ATAPI Removable Media
 Device. These include, but are not limited to:
 ZIP
 LS-120

LBA/Large Mode [Auto]

Use the **LBA/Large Mode** option to disable or enable BIOS to auto detects LBA (Logical Block Addressing). LBA is a method of addressing data on a disk drive. In LBA mode, the maximum drive capacity is 137 GB.

→	Disabled		BIOS is prevented from using the LBA mode control on the specified channel.
→	Auto	DEFAULT	BIOS auto detects the LBA mode control on the specified channel.

Block (Multi Sector Transfer) [Auto]

Use the **Block (Multi Sector Transfer)** to disable or enable BIOS to auto detect if the device supports multi-sector transfers.

- Disabled BIOS is prevented from using Multi-Sector Transfer on the specified channel. The data to and from the device occurs one sector at a time.
- → Auto DEFAULT BIOS auto detects Multi-Sector Transfer support on the drive on the specified channel. If supported the data transfer to and from the device occurs multiple sectors at a time.

PIO Mode [Auto]

Use the **PIO Mode** option to select the IDE PIO (Programmable I/O) mode program timing cycles between the IDE drive and the programmable IDE controller. As the PIO mode increases, the cycle time decreases.

→	Auto	DEFAULT	BIOS auto detects the PIO mode. Use this value if the IDE disk
			drive support cannot be determined.
→	0		PIO mode 0 selected with a maximum transfer rate of 3.3 MB/s
→	1		PIO mode 1 selected with a maximum transfer rate of 5.2 MB/s
→	2		PIO mode 2 selected with a maximum transfer rate of 8.3 MB/s
→	3		PIO mode 3 selected with a maximum transfer rate of 11.1 MB/s
→	4		PIO mode 4 selected with a maximum transfer rate of 16.6 MB/s
			(This setting generally works with all hard disk drives
			manufactured after 1999. For other disk drives, such as IDE
			CD-ROM drives, check the specifications of the drive.)

DMA Mode [Auto]

Use the **DMA Mode** BIOS selection to adjust the DMA mode options.

→	Auto	DEFAULT	BIOS auto detects the DMA mode. Use this value if the IDE disk drive support cannot be determined.
→	SWDMA0		Single Word DMA mode 0 selected with a maximum data transfer rate of 2.1 MB/s
→	SWDMA1		Single Word DMA mode 1 selected with a maximum data transfer rate of 4.2 MB/s
→	SWDMA2		Single Word DMA mode 2 selected with a maximum data transfer rate of 8.3 MB/s
→	MWDMA0		Multi Word DMA mode 0 selected with a maximum data transfer rate of 4.2 MB/s
→	MWDMA1		Multi Word DMA mode 1 selected with a maximum data transfer rate of 13.3 MB/s
→	MWDMA2		Multi Word DMA mode 2 selected with a maximum data transfer rate of 16.6 MB/s
→	UDMA0		Ultra DMA mode 0 selected with a maximum data transfer rate of 16.6 MB/s

→	UDMA1	Ultra DMA mode 1 selected with a maximum data transfer rate of 25 MB/s
→	UDMA2	Ultra DMA mode 2 selected with a maximum data transfer rate of 33.3 MB/s
→	UDMA3	Ultra DMA mode 3 selected with a maximum data transfer rate of 44 MB/s (To use this mode, it is required that an 80-conductor ATA cable is used.)
→	UDMA4	Ultra DMA mode 4 selected with a maximum data transfer rate of 66.6 MB/s (To use this mode, it is required that an 80-conductor ATA cable is used.)
→	UDMA5	Ultra DMA mode 5 selected with a maximum data transfer rate of 99.9 MB/s (To use this mode, it is required that an 80-conductor ATA cable is used.)

S.M.A.R.T [Auto]

Use the **S.M.A.R.T** option to auto-detect, disable or enable Self-Monitoring Analysis and Reporting Technology (SMART) on the drive on the specified channel. **S.M.A.R.T** predicts impending drive failures. The **S.M.A.R.T** BIOS option enables or disables this function.

→	Auto	DEFAULT	BIOS auto detects HDD SMART support.
→	Disabled		Prevents BIOS from using the HDD SMART feature.
→	Enabled		Allows BIOS to use the HDD SMART feature

32Bit Data Transfer [Enabled]

Use the **32Bit Data Transfer** BIOS option to enables or disable 32-bit data transfers.

- Disabled
 Prevents the BIOS from using 32-bit data transfers.
- Enabled DEFAULT Allows BIOS to use 32-bit data transfers on supported hard disk drives.

5.3.3 Super IO Configuration

Use the **Super IO Configuration** menu (BIOS Menu 6) to set or change the configurations for the FDD controllers, parallel ports and serial ports.

	BIOS SETUR	OUTILITY		
Main Advanced P	CIPNP Boot	Security	Chipset	Exit
Configure Super I/O Ch	ipset			BIOS to select Port Base
Serial Portl Address Serial Portl IRQ Serial Port2 Address Serial Port2 IRQ	[3F8] [4] [2F8] [3]		Addres	ses
			↑↓ Enter F1 F10	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
v02.61 ©Coj	pyright 1985-2006,	American	Megatrends,	Inc.

BIOS Menu 6: Super IO Configuration

Serial Port1 Address [3F8]

Sets the port address of serial port 1.

- Disabled
- 3F8 **Default**
- 2F8
- 3E8
- 2E8
- Serial Port1 IRQ [4]

Sets the interrupt request for serial port 1.

- 3
- 4 DEFAULT
- Serial Port2 Address [2F8]

Sets the port address of serial port 2.

- Disabled
- 3F8
- 2F8 **DEFAULT**
- 3E8
- 2E8
- Serial Port2 IRQ [3

Sets the interrupt request for serial port 2.

3 DEFAULT
 4

5.3.4 Power Configuration

The Power Configuration menu (BIOS Menu 7) configures the power options.

			_	P UTILITY			
Main	Advanced	PCIPNP	Boot	Security	Chipset	Power	Exit
> ACPI Co	Sumper Sett: onfiguration	ing	[ATX]		←→ ↑↓ Enter F1 F10	Select S Select I Go to Su General Save and	tem bScreen Help
					ESC	Exit	
	v02.61 @	Copyright	1985-2006	, American	Megatrends	s, Inc.	

BIOS Menu 7: Power Configuration

Current Jumper Setting [ATX]

Shows the setting of the Power Selection Jumper.

- ATX DEFAULT
- AT

5.3.4.1 ACPI Configuration

Use the **ACPI Configuration** menu (**BIOS Menu 8**) to select the ACPI state when the system is suspended.

General ACPI Configuration Suspend Mode [S1(POS)] ←→ Select Screen ↑↓ Select Item Enter Go to SubScreen F1 General Help F10 Save and Exit ESC Exit					P UTILITY				
Suspend Mode [S1(POS)] Select Screen ↑↓ Select Item Enter Go to SubScreen	Main	Advanced	PCIPNP	Boot	Security	Chir	set	Power	Exit
←→ Select Screen ↑↓ Select Item Enter Go to SubScreen F1 General Help F10 Save and Exit ESC Exit	General	ACPI Config	uration						
↑↓ Select Item Enter Go to SubScreen F1 General Help F10 Save and Exit ESC Exit	Suspend	Mode		[S1(PO	S)]				
							<pre>↑ ↓ Enter F1 F10 ESC</pre>	Select Go to S General Save an Exit	Item SubScreen Help
v02.61 ©Copyright 1985-2006, American Megatrends, Inc.		v02.61	©Copyright	1985-2006	, American	Mega	trends	, Inc.	

BIOS Menu 8: General ACPI Configuration

Suspend Mode [S1(POS)]

Use the **Suspend Mode** option to specify the sleep state the system enters when it is not being used.

→	S1 (POS)	DEFAULT	Caches are flushed, CPU stops executing instructions,
			power to CPU and RAM maintained and some peripheral
			devices powered down
→	S3 (STR)		Same as S1, but CPU state is written to RAM, and CPU is
			powered off

5.3.4.2 APM Configuration

The **APM Configuration** menu (BIOS Menu 9) allows the advanced power management options to be configured.

	BIOS SETUP UTILITY						
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit	
Restore c Power But	on AC Power ton Mode	Loss	[Power [On/Of:				
Resume Or Resume or Resume or	<u> </u>		[Disab] [Disab] [Disab]	led]			
					F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit	
	v02.61 @	Copyright	1985-2006	, American	Megatrends	, Inc.	

BIOS Menu 9: APM Configuration

Restore on AC Power Loss [Power Off]

Use the **Restore on AC Power Loss** BIOS option to specify what state the system returns to if there is a sudden loss of power to the system.

- Power Off
 The system remains turned off
- Power On DEFAULT The system turns on
- ➔ Last State The system returns to its previous state. If it was on, it turns itself on. If it was off, it remains off.
- Power Button Mode [On/Off]

Use the **Power Button Mode** BIOS to specify how the power button functions.

→	On/Off	DEFAULT	When the power button is pressed the system is either turned on or off
→	Suspend		When the power button is pressed the system goes into suspend mode

Resume on Ring [Disabled]

Use the **Resume on Ring** BIOS option to enable activity on the RI (ring in) modem line to rouse the system from a suspend or standby state. That is, the system will be roused by an incoming call on a modem.

→	Disabled	DEFAULT	Wake event not generated by an incoming call
→	Enabled		Wake event generated by an incoming call

Resume on LAN [Disabled]

When enabled this option allows the system to be brought out of a sleep state by a special packet sent over the network.

→	Disabled	DEFAULT	Won't wake if special packet sent
→	Enabled		Will leave sleep state when special packet is sensed
			on the network

Resume on RTC Alarm [Disabled]

Use the **Resume on RTC Alarm** option to specify the time the system should be roused from a suspended state.

→	Disabled	DEFAULT	The real time clock (RTC) cannot generate a wake
			event
→	Enabled		If selected, the following appears with values that
			can be selected:
			RTC Alarm Date (Days)
			System Time
			After setting the alarm, the computer turns itself on
			from a suspend state when the alarm goes off.

5.3.5 Remote Access Configuration

Use the **Remote Access Configuration** menu (BIOS Menu 10) to configure remote access parameters. The **Remote Access Configuration** is an AMIBIOS feature and

allows a remote host running a terminal program to display and configure the BIOS settings.

			BIOS SETU	JP UTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
Configure	Configure Remote Access type and parameters					
Remote Ac	cess		[Disab	led]		
Base Serial Po	on After B		[COM1] [3F8H, [11520 [Alway [ANSI]	4] 0 8,n,1] s]	←→ ↑↓ Enter F1 F10 ESC	Select Item Go to SubScreen General Help Save and Exit
	v02.61 @	Copyright	1985-2006	5, American	Megatrends	, Inc.

BIOS Menu 10: Remote Access Configuration

Remote Access [Disabled]

Use the **Remote Access** option to enable or disable access to the remote functionalities of the system.

→	Disabled	DEFAULT	Remote access is disabled.
→	Enabled		Remote access configuration options shown below
			appear:
			Serial Port Number
			Serial Port Mode
			Flow Control
			Redirection after BIOS POST
			Terminal Type
			VT-UTF8 Combo Key Support
			These configuration options are discussed below.

Serial Port Number [COM1]

Use the **Serial Port Number** option allows to select the serial port used for remote access.

→	COM1	DEFAULT	System is remotely accessed through COM1
---	------	---------	--

→ COM2 System is remotely accessed through COM2

NOTE: Make sure the selected COM port is enabled through the Super I/O configuration menu.

Base Address, IRQ [3F8h,3]

The **Base Address**, **IRQ** option cannot be configured and only shows the interrupt address of the serial port listed above.

Serial Port Mode [115200 8,n,1]

Use the **Serial Port Mode** option to select baud rate through which the console redirection is made. The following configuration options are available


- 115200 8,n,1 **DEFAULT**
- 57600 8,n,1
- 38400 8,n,1
- 19200 8,n,1
- 09600 8,n,1



Identical baud rate setting musts be set on the host (a management computer running a terminal software) and the slave

Redirection After BIOS POST [Always]

Use the **Redirection After BIOS POST** option to specify when console redirection should occur.



➔ Always DEFAULT Redirection is always active (Some OSes may not work if set to Always)

Terminal Type [ANSI]

Use the Terminal Type BIOS option to specify the remote terminal type.

→	ANSI	DEFAULT	The target terminal type is ANSI
→	VT100		The target terminal type is VT100
→	VT-UTF8		The target terminal type is VT-UTF8

5.3.6 USB Configuration

Use the **USB Configuration** menu (BIOS Menu 11) to read USB configuration information and configure the USB settings.

	BIOS SETUP	UTILITY		
Main Advanced PCIPNP	Boot	Security	Chipset	Exit
USB Configuration				es support for y USB. AUTO
Module Version - 2.24.3-13.4			optio	n disables y support if
USB Devices Enabled: None			no US conne	B devices are cted
USB Functions USB 2.0 Ports Enable Legacy USB Support USB 2.0 Controller Mode	[Enabled [Enabled [Enabled [HiSpeed	d] d]	←→ ↑↓ Enter F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
v02.61 ©Copyrigh	t 1985-2006,	American	Megatrends	, Inc.

BIOS Menu 11: USB Configuration

USB Function [Enabled]

When enabled, USB devices can be used in the USB slots.

- Disabled **DEFAULT**
- Enabled

USB 2.0 Ports Enabled [Enabled]

The USB ports will only operate in the legacy USB 1.1 mode unless this setting is enabled.

- Disabled **DEFAULT**
- Enabled

Legacy USB Support [Enabled]

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support.

Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

→	Disabled		Legacy USB support disabled
→	Enabled	DEFAULT	Legacy USB support enabled
→	Auto		Legacy USB support disabled if no USB devices are
			connected

USB2.0 Controller Mode [HiSpeed]

Use the USB2.0 Controller Mode option to set the speed of the USB2.0 controller.

→	FullSpeed		The controller is capable of operating at 12 Mb/s
→	HiSpeed	DEFAULT	The controller is capable of operating at 480 Mb/s

5.3.6.1 USB Mass Storage Device Configuration

Use the **USB Mass Storage Device Configuration** menu (BIOS Menu 12) to configure USB mass storage class devices.

			BIOS SETUR	VTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
USB Mass	Storage Dev	vice Confi	guration			
USB Mass	Storage Rea	set Delay	[20 Sec]		
Device Emulati	#1 on Type	M-SysT5	Dell Memor [Auto]	y Key 5.04	ł	
					↑↓ Enter F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
	v02.61 @	Copyright	1985-2006,	American	Megatrends	, Inc.

BIOS Menu 12: USB Mass Storage Device Configuration

USB Mass Storage Reset Delay [20 Sec]

Use the **USB Mass Storage Reset Delay** option to set the number of seconds POST waits for the USB mass storage device after the start unit command.

→	10 Sec		POST waits 10 seconds for the USB mass storage device after the start unit command.
→	20 Sec	DEFAULT	POST waits 20 seconds for the USB mass storage device after the start unit command.
→	30 Sec		POST waits 30 seconds for the USB mass storage device after the start unit command.
→	40 Sec		POST waits 40 seconds for the USB mass storage device after the start unit command.

Device

The **Device##** field lists the USB devices that are connected to the system.

Emulation Type [Auto]

Use the **Emulation Type** BIOS option to specify the type of emulation BIOS has to provide for the USB device.

→	Auto	DEFAULT	BIOS auto-detects the current USB.
→	Floppy		The USB device will be emulated as a floppy drive. The device can be either A: or B: responding to INT13h calls that return $DL = 0$ or $DL = 1$ respectively.
→	Forced FDD		Allows a hard disk image to be connected as a floppy image. This option works only for drives formatted with FAT12, FAT16 or FAT32.
→	Hard Disk		Allows the USB device to be emulated as hard disk responding to INT13h calls that return DL values of 80h or above.
→	CDROM		Assumes the CD-ROM is formatted as bootable media. All the devices that support block sizes greater than 512 bytes can only be booted using this option.

5.4 PCI/PnP

Use the **PCI/PnP** menu (BIOS Menu 13) to configure advanced PCI and PnP settings.



Setting wrong values for the BIOS selections in the PCIPnP BIOS menu may cause the system to malfunction.

	BIOS SETUP UTILI	ТҮ
Main Advanced PCI	PNP Boot Securi	ty Chipset Exit
Advanced PCI/PnP Setting	S	Available: Specified IRO is available to be
WARNING: Setting wrong v	alues in below section	
may cause syste	m to malfunction	devices.
IRQ3	[Reserved]	Reserved: Specified
IRQ4	[Reserved]	IRQ is reserved for
IRQ5	[Available]	use by Legacy ISA
IRQ7	[Available]	devices.
IRQ9	[Available]	
IRQ10	[Available]	
IRQ11	[Available]	
IRQ14	[Available]	
IRQ15	[Available]	
DMA Channel 0	[Available]	
DMA Channel 1	[Available]	
DMA Channel 3	[Available]	\leftrightarrow Select Screen
DMA Channel 5	[Available]	↑↓ Select Item
DMA Channel 6	[Available]	Enter Go to SubScreen
DMA Channel 7	[Available]	F1 General Help
		F10 Save and Exit
Reserved Memory Size	[Disabled]	ESC Exit
v02.61 ©Copy	right 1985-2006, Ameri	can Megatrends, Inc.

BIOS Menu 13: PCI/PnP Configuration

IRQ# [Available]

Use the **IRQ#** address to specify what IRQs can be assigned to a particular peripheral device.

→	Available	DEFAULT	The specified IRQ is available to be used by PCI/PnP devices
→	Reserved		The specified IRQ is reserved for use by Legacy ISA devices

Available IRQ addresses are:

- IRQ3
- IRQ4
- IRQ5
- IRQ7
- IRQ9

Page 50

- IRQ10
- IRQ 11
- IRQ 14
- IRQ 15

DMA Channel# [Available]

Use the **DMA Channel#** option to assign a specific DMA channel to a particular PCI/PnP device.

→	Available	DEFAULT	The specified DMA is available to be used by PCI/PnP devices
→	Reserved		The specified DMA is reserved for use by Legacy ISA devices

Available DMA Channels are:

- DM Channel 0
- DM Channel 1
- DM Channel 3
- DM Channel 5
- DM Channel 6
- DM Channel 7

Reserved Memory Size [Disabled]

Use the **Reserved Memory Size** BIOS option to specify the amount of memory that should be reserved for legacy ISA devices.

→	Disabled	DEFAULT	No memory block reserved for legacy ISA devices
→	16K		16 KB reserved for legacy ISA devices
→	32K		32 KB reserved for legacy ISA devices
→	64K		54 KB reserved for legacy ISA devices

5.5 Boot

			BIOS SETUR	P UTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
Boot Set	tings					gure settings g system boot.
> Boot S	ettings Conf	iguration				
> Hard D. > CD/DVD	evice Priori isk Drives Drives ble Drives	ty			$\uparrow \downarrow$	Select Screen Select Item Go to SubScreen General Help
					F10 ESC	Save and Exit Exit
	v02.61 @	Copyright	1985-2006	, American	Megatrends	, Inc.
В	IOS Menu 14:	Boot				

Use the **Boot** menu (BIOS Menu 14) to configure system boot options.

5.5.1 Boot Settings Configuration

Use the **Boot Settings Configuration** menu (BIOS Menu 15) to configure advanced system boot options.

		BIOS SETU	IP UTILITY		
Main Advanced	PCIPNP	Boot	Security	Chipset	Exit
Boot Settings Conf.	iguration				s BIOS to skip in tests while
Quick Boot Quiet Boot AddOn ROM Display I Bootup Num-Lock	1ode	[Enabl [Enabl [Force [On]		decre	ng. This will ase the time needed ot the system.
Boot from LAN Supp	ort	[Disab	led]	←→ ↑ ↓ Enter F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
v02.61	©Copyright	1985-2006	, American	Megatrends	, Inc.

BIOS Menu 15: Boot Settings Configuration

Quick Boot [Enabled]

Use the Quick Boot BIOS option to make the computer speed up the boot process.

→	Disabled		No POST procedures are skipped
→	Enabled	DEFAULT	Some POST procedures are skipped to decrease
			the system boot time

Quiet Boot [Disabled]

Use the Quiet Boot BIOS option to select the screen display when the system boots.

→	Disabled	DEFAULT	Normal POST messages displayed
→	Enabled		OEM Logo displayed instead of POST messages

AddOn ROM Display Mode [Force BIOS]

Use the **AddOn ROM Display Mode** option to allow add-on ROM (read-only memory) messages to be displayed.

→	Force BIOS	DEFAULT	The system forces third party BIOS to display during system boot.
→	Keep Current		The system displays normal information during system boot.

Bootup Num-Lock [On]

Use the **Bootup Num-Lock** BIOS option to specify if the number lock setting must be modified during boot up.

Off Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged.

➤ On DEFAULT Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit.

Boot From LAN Support [Disabled]

Use the **BOOT From LAN Support** option to enable the system to be booted from a remote system.

→	Disabled	DEFAULT	Cannot be booted from a remote system through the LAN
→	Enabled		Can be booted from a remote system through the LAN

5.5.2 Boot Device Priority

Use the **Boot Device Priority** menu (BIOS Menu 16) to specify the boot sequence from the available devices. The drive sequence also depends on the boot sequence in the individual device section.

Main	Advanced	PCIPNP	BIOS SE Boot	TUP UTILITY	Chipset	: Exit
Boot Devic > 1st Boot > 2nd Boot > 3rd Boot	Device		[2nd	Boot Device Boot Device Boot Device	se [] av	ecifies the boot quence from the ailable devices.
					↑ En F1	ter Go to SubScreen General Help 0 Save and Exit
	v02.61 ©	Copyright	1985-20	06, American	n Megatre	nds, Inc.

BIOS Menu 16: Boot Device Priority Settings

5.5.3 Hard Disk Drives

Use the **Hard Disk Drives** menu to specify the boot sequence of the available HDDs. Only installed hard drives are shown.

	BIOS SET	UP UTILITY		
Main Advanced PCIPNP	Boot	Security	Chipset	Exit
Hard Disk Drives			-	fies the boot ence from the
> 1st Drive	[Hard	Drive 1]	avail	able devices.
> 2nd Drive	[Hard	Drive 2]		
> 3rd Drive	[Hard	Drive 3]		
v02 61 @Copyrright	1005 200	6 Imoriaan	↑↓ Enter F1 F10 ESC	Go to SubScreen General Help Save and Exit Exit
v02.61 ©Copyright	1985-200	6, American	Megatrends	s, Inc.

BIOS Menu 17: Hard Disk Drives

5.5.4 Removable Drives

Use the **Removable Drives** menu (BIOS Menu 18) to specify the boot sequence of the removable drives. Only connected drives are shown.

Main	Advanced	PCIPNP	BIOS SETU Boot	P UTILITY Security	Chipset	Exit
Hard Dist > 1st Dr > 2nd Dr > 3rd Dr	k Drives ive ive	PCIPNP	[Remova [Remova	able Drive able Drive able Drive	Spe seq 1] ava 2]	cifies the boot uence from the ilable devices.
					↑↓ Ent F1 F10 ESC	er Go to SubScreen General Help Save and Exit Exit
	v02.61 @	Copyright	1985-2006	, American	Megatren	ds, Inc.

BIOS Menu 18: Removable Drives

5.5.5 CD/DVD Drives

Use the **CD/DVD Drives** menu to specify the boot sequence of the available CD/DVD drives. When the menu is opened, the CD drives and DVD drives connected to the system are listed as shown below:

- 1st Drive [CD/DVD: PM-(part ID)]
- 2nd Drive [HDD: PS-(part ID)]
- 3rd Drive [HDD: SM-(part ID)]
- 4th Drive [HDD: SM-(part ID)]



Only the drives connected to the system are shown. For example, if only two CDs or DVDs are connected only "**1st Drive**" and "**2nd Drive**" are listed.

The boot sequence from the available devices is selected. If the "**1st Drive**" option is selected a list of available CD/DVD drives is shown. Select the first CD/DVD drive the system boots from. If the "**1st Drive**" is not used for booting this option may be disabled.

	BIOS SETU	P UTILITY		
Main Advanced PCI	PNP Boot	Security	Chipset	Exit
Hard Disk Drives			sequei	fies the boot nce from the
> 1st Drive	[CD/DVD	-	availa	able devices.
> 2nd Drive > 3rd Drive	[CD/DVD [CD/DVD			
			↑↓ Enter F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
v02.61 ©Copy	right 1985-2006	, American	Megatrends	, Inc.

BIOS Menu 19: CD/DVD Drives

5.6 Security

Use the Security menu (BIOS Menu 20) to set system and user passwords.

BIOS SETUP UTILITY									
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit			
Security	Settings			-					
Superviso User Pass			Installed Installed						
<u> </u>	upervisor Pa ser Password				↑↓ Enter F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit			
	v02.61 ©	Copyrigł	nt 1985-2000	5, American	Megatrends	, Inc.			
В	IOS Menu 20:	Security	,						

Change Supervisor Password

Use the **Change Supervisor Password** to set or change a supervisor password. The default for this option is **Not Installed**. If a supervisor password must be installed, select this field and enter the password. After the password has been added, **Install** appears next to **Change Supervisor Password**.

Change User Password

Use the **Change User Password** to set or change a user password. The default for this option is **Not Installed**. If a user password must be installed, select this field and enter the password. After the password has been added, **Install** appears next to **Change User Password**.

5.7 Chipset

Use the **Chipset** menu (BIOS Menu 21) to access the Northbridge and Southbridge configuration menus




Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.

			BIOS SETU	P UTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
Advanced	Chipset Set	tings			Optio	ns for VIA® VX800
	ridge VIA® N ridge VIA® N		2			
					$\uparrow \downarrow$	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
	v02.61 @	Copyright	1985-2006	, American	Megatrends	, Inc.

BIOS Menu 21: Chipset

5.7.1 Northbridge VIA® VX800 Configuration

Use the Northbridge VIA® VX800 Configuration configures the system chipset.



BIOS Menu 22:Northbridge Chipset Configuration

VGA Frame Buffer Size [Auto]

Specifies how much memory is allocated to the graphics.

- 8MB
- 16MB
- 32MB
- 64MB
- 128MB **DEFAULT**
- 256MB

5.7.2 Southbridge VIA® VX800 Configuration

The Southbridge VIA® VX800 Configuration configures the system chipset.

				P UTILITY		
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit
Southbrid	dge Configu	ration			Optio	ns
High Def:	inition Aud:	io	[Auto]		Disab Auto	led
					←→ ↑↓ Enter F1 F10 ESC	Select Screen Select Item Go to SubScreen General Help Save and Exit Exit
	v02.61 @	Copyright	1985-2006	, American	Megatrends	, Inc.

BIOS Menu 23:Southbridge Chipset Configuration

HD Audio Azalia Device [Enabled]

Enables and disables the onboard audio.

→	Disabled		Audio chip disabled
→	Auto	DEFAULT	Audio chip enabled if audio devices are attached

5.8 Exit

Use the **Exit** menu (BIOS Menu 24) to load default BIOS values, optimal failsafe values and to save configuration changes.

			BIOS SETU	P UTILITY			
Main	Advanced	PCIPNP	Boot	Security	Chipset	Exit	
Exit Opti	ions					system se g the cha	tup after nges.
	nges and Exi Changes and Changes					ey can be operation	used for
-	imal Default Isafe Defaul				←→ ↑↓ Enter F1 F10 ESC	Select I Go to Su General Save and	tem bScreen Help
	v02.61 @	Copyright	1985-2006	, American	Megatrends	, Inc.	

BIOS Menu 24:Exit

Save Changes and Exit

Use the **Save Changes and Exit** option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.

Discard Changes and Exit

Use the **Discard Changes and Exit** option to exit the BIOS configuration setup program without saving the changes made to the system.

Discard Changes


Use the **Discard Changes** option to discard the changes and remain in the BIOS configuration setup program.

Load Optimal Defaults

Use the **Load Optimal Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F9 key can be used for this operation.**

Load Failsafe Defaults

Use the Load Failsafe Defaults option to load failsafe default values for each of the parameters on the Setup menus. F8 key can be used for this operation.



Safety Precautions

A.1 Safety Precautions

🖄 WARNING:

The precautions outlined in this appendix should be strictly followed. Failure to follow these precautions may result in permanent damage to the uIBX-200-VX800.

Please follow the safety precautions outlined in the sections that follow:

A.1.1 General Safety Precautions

Please ensure the following safety precautions are adhered to at all times.

- Make sure the power is turned off and the power cord is disconnected when moving, installing or modifying the system.
- Do not apply voltage levels that exceed the specified voltage range.
 Doing so may cause fire and/or an electrical shock.
- Electric shocks can occur if opened while still powered on.
- Do not drop or insert any objects into the ventilation openings.
- If considerable amounts of dust, water, or fluids enter the system, turn off the power supply immediately, unplug the power cord, and contact the system vendor.
- DO NOT:
 - O Drop the system against a hard surface.
 - O Strike or exert excessive force onto the LCD panel.
 - O Touch any of the LCD panels with a sharp object
 - O In a site where the ambient temperature exceeds the rated temperature

A.1.2 Anti-static Precautions



Failure to take ESD precautions during the installation of the uIBX-200-VX800 may result in permanent damage to the uIBX-200-VX800 and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the uIBX-200-VX800. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the uIBX-200-VX800 is opened and any of the electrical components are handled, the following anti-static precautions are strictly adhered to.

- Wear an anti-static wristband: Wearing a simple anti-static wristband can help to prevent ESD from damaging any electrical component.
- Self-grounding: Before handling any electrical component, touch any grounded conducting material. During the time the electrical component is handled, frequently touch any conducting materials that are connected to the ground.
- Use an anti-static pad: When configuring or working with an electrical component, place it on an antic-static pad. This reduces the possibility of ESD damage.
- Only handle the edges of the electrical component. When handling the electrical component, hold the electrical component by its edges.

A.2 Maintenance and Cleaning Precautions

When maintaining or cleaning the uIBX-200-VX800, please follow the guidelines below.

A.2.1 Maintenance and Cleaning

Prior to cleaning any part or component of the uIBX-200-VX800, please read the details below.


 Except for the LCD panel, never spray or squirt liquids directly onto any other components. To clean the LCD panel, gently wipe it with a piece of soft dry cloth or a slightly moistened cloth.

- The interior of the uIBX-200-VX800 does not require cleaning. Keep fluids away from the uIBX-200-VX800 interior.
- Be cautious of all small removable components when vacuuming the uIBX-200-VX800.
- Turn the uIBX-200-VX800 off before cleaning the uIBX-200-VX800.
- Never drop any objects or liquids through the openings of the uIBX-200-VX800.
- Be cautious of any possible allergic reactions to solvents or chemicals used when cleaning the uIBX-200-VX800.
- Avoid eating, drinking and smoking within vicinity of the uIBX-200-VX800.

A.2.2 Cleaning Tools

Some components in the uIBX-200-VX800 may only be cleaned using a product specifically designed for the purpose. In such case, the product will be explicitly mentioned in the cleaning tips. Below is a list of items to use when cleaning the uIBX-200-VX800.

- *Cloth* Although paper towels or tissues can be used, a soft, clean piece of cloth is recommended when cleaning the uIBX-200-VX800.
- Water or rubbing alcohol A cloth moistened with water or rubbing alcohol can be used to clean the uIBX-200-VX800.
- Using solvents The use of solvents is not recommended when cleaning the uIBX-200-VX800 as they may damage the plastic parts.
- Vacuum cleaner Using a vacuum specifically designed for computers is one of the best methods of cleaning the uIBX-200-VX800. Dust and dirt can restrict the airflow in the uIBX-200-VX800 and cause its circuitry to corrode.
- Cotton swabs Cotton swaps moistened with rubbing alcohol or water are excellent tools for wiping hard to reach areas.
- **Foam swabs** Whenever possible, it is best to use lint free swabs such as foam swabs for cleaning.



Hazardous Materials Disclosure

B.1 Hazardous Materials Disclosure Table for Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated "Environmentally Friendly Use Period" (EFUP). This is an estimate of the number of years that these substances would "not leak out or undergo abrupt change." This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

Part Name Toxic or Hazardous Substances and Elements							
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)	
Housing	х	0	0	0	0	Х	
Display	х	0	0	0	0	Х	
Printed Circuit Board	х	0	0	0	0	Х	
Metal Fasteners	х	0	0	0	0	0	
Cable Assembly	х	0	0	0	0	Х	
Fan Assembly	х	0	0	0	0	Х	
Power Supply Assemblies	х	0	0	0	0	X	
Battery	0	0	0	0	0	0	
 O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006 X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for 							

this part is above the limit requirement in SJ/T11363-2006

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符 合中国 RoHS 标准规定的限量要求。

本产品上会附有"环境友好使用期限"的标签,此期限是估算这些物质"不会有泄漏或突变"的 年限。本产品可能包含有较短的环境友好使用期限的可替换元件,像是电池或灯管,这些元 件将会单独标示出来。

部件名称 有毒有害物质或元素							
	铅	汞	镉	六价铬	多溴联苯	多溴二苯	
	(Pb)	(Hg)	(Cd)	(CR(VI))	(PBB)	醚	
						(PBDE)	
壳体	Х	0	0	0	0	Х	
显示	Х	0	0	0	0	Х	
印刷电路板	Х	0	0	0	0	Х	
金属螺帽	х	0	0	0	0	0	
电缆组装	х	0	0	0	0	х	
风扇组装	х	0	0	0	0	х	
电力供应组装	х	0	0	0	0	Х	
电池	0	0	0	0	0	0	
O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。							
X:表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。							