

BIOS Update Procedure

1. Copy files from <bios.zip> to a USB stick (formatted FAT32)
2. Boot module into EFI shell
3. Change to the drive representing the USB stick
Type fsx: (x = 0,1,2,etc represents the USB stick)
4. Change to the directory where you copied files from <bios.zip>.
5. Type flash.nsh
6. Wait until flashing is successful and then power cycle the board.

For Kflash:

- 1) Copy files from <bios.bin> to a USB stick (formatted FAT32)
- 2) Boot to the UEFI prompt
- 3) map -r (I think only necessary if flash drive is plugged in after the shell comes up)
- 4) Type 'kflash -p FS0:\new_image.bin'